

# SENECA XVAULT STORAGE QUICK START GUIDE

## XVAULT ST3000EX

### THIS PRODUCT MUST BE REGISTERED WHEN CONNECTED TO THE ST3000

**ONLY** IF EXPANSION ENCLOSURES ARE CONNECTED TO OR DAISY CHAINED FROM A ST3000 STORAGE APPLIANCE IS IT NECESSARY TO REGISTER AN ENCLOSURE. WITHOUT REGISTRATION, DRIVES IN THE EXPANSION ENCLOSURE WILL NOT BE USABLE UNTIL A NEW LICENSE IS APPLIED.

#### CONTENTS OF XVAULT PACKAGE

Quantity	Item
1	Expansion chassis
1	Set of slide rails including hardware
2	AC power cords
1	SAS external cable
1	SAS daisy chain cable 4U 48 Bay only

Email Seneca the serial number and software serial number located on top left front corner of enclosure to:


**storage\_license@senecadata.com**

A license file will be emailed back to enable use of new drives. The new license will replace the old license. Refer to the manual which can be found on the ST3000 GUI under tab "Support", then "Support Portal" and click on "Single controller 3U & 4U" or download from:


<http://products.senecadata.com/PDF/support/ST3000-Manual-V2.pdf>

### ONLY REGISTER IF ATTACHED DIRECTLY TO OR DAISY CHAINED FROM A ST3000 STORAGE APPLIANCE

#### CABLING DIAGRAM FOR 2U 12 BAY, 3U 16 BAY, AND 4U 24 BAY




#### DEFAULT CABLING DIAGRAM FOR 4U 24 BAY



Default cabling for a single server configuration. This will present all 48 drives to the server.


#### DUAL SERVER ACCESS CABLING DIAGRAM FOR 4U 24 BAY



Each server can see up to 24 drives. **DRIVES CANNOT BE SHARED BETWEEN SERVERS.**

## DRIVE SLOT LOCATIONS BY CHASSIS MODEL


### 2U 12 BAY




### 4U 24 BAY



### 3U 16 BAY



### 4U 48 BAY TOP INSIDE VIEW WITH FRONT PANEL DISPLAY



## Manual Location:

The online manual link in PDF format can be opened by navigating from the log in screen by selecting **Support** then selecting **Support Portal**.

The manual can also be downloaded at

<http://products.senecadata.com/PDF/support/storage/ST3000-manual-V2.PDF>.

## XVAULT SUPPORT

Seneca customer care group stand ready to assist with any hardware and operating system assistance.

### Contact Seneca Digital Security and Surveillance Support:

Normal Business Hours

**800.227.3432 option 5**

Available Monday–Friday 8am–6pm EST

**First level of data protection and integrity begins with AC power protection.**

**Please consult your Seneca Account Manager for properly sized, uninterruptable power supply (UPS).**